

**ZONGE GGT-10**  
**GEOPHYSICAL TRANSMITTER**  
**MAINTENANCE and REPAIR MANUAL**

*March, 2001*

**Zonge International**  
3322 East Fort Lowell Road, Tucson, AZ 85716 USA  
Phone (520) 327-5501 Facsimile (520) 325-1588

*Blank Page*

# TABLE OF CONTENTS

<b>TABLE OF FIGURES.....</b>	<b>4</b>
<b>1. INTRODUCTION.....</b>	<b>5</b>
<b>2. GGT-10 SPECIFICATIONS .....</b>	<b>6</b>
2.1. Electrical .....	6
2.2. Mechanical.....	6
2.3. Electronics.....	6
2.4. Front Panel Controls .....	7
2.5. Controls.....	7
2.6. External Control.....	7
<b>3. OPERATING INSTRUCTIONS .....</b>	<b>8</b>
3.1. First Time Operation.....	8
3.2. Motor-Generator Hook-up Procedure (ZMG-Series).....	9
3.3. Description of Controls .....	10
<b>4. THEORY OF OPERATION .....</b>	<b>12</b>
4.1. Board 204.....	12
4.2. Board 93.....	12
4.3. Board 131.....	13
4.4. Board 99 - Output Pulse Amplifiers   DANGER - HIGH VOLTAGE .....	15
4.5. Boards 175, 176 - Meter Circuits .....	15
<b>5. TROUBLE-SHOOTING PROCEDURES .....</b>	<b>15</b>
5.1. High Voltage Areas, Board 99 SCR's, Heat sink IGBT's .....	15
5.2. Disassembly .....	15
5.3. Heat Sink Removal .....	16
5.4. Board 204 - INSULATED GATE BIPOLAR TRANSISTOR Drive .....	16
5.5. Board 93 - Output Switch Control .....	19
5.6. Board 131 - Current Feedback and SCR Drive Signals .....	21
5.7. Power Supply - See Addendum Power Supply (data sheet).....	24
5.8. Meter Circuits .....	24
<b>6. APPENDIX.....</b>	<b>26</b>
6.1. Checking Phase Sequence - Alternator .....	26
6.2. Options.....	27
6.3. Transmitter Front Panel Lamp Functions.....	27
6.4. Transmitter Display Operation.....	28

## TABLE OF FIGURES

<i>Figure 1.</i>	<i>Safe operating curves for GGT-10</i>	<i>Fig01.eps</i>
<i>Figure 2.</i>	<i>Output Waveforms</i>	<i>Fig02.eps</i>
<i>Figure 3.</i>	<i>GGT-10, Front Panel</i>	<i>Fig03.gif</i>
<i>Figure 4.</i>	<i>Board 204</i>	<i>Fig04.gif</i>
<i>Figure 5.</i>	<i>Board 204</i>	<i>Fig05.gif</i>
<i>Figure 6.</i>	<i>IGBT, Diode, SCR illustrations</i>	<i>Fig06.gif</i>
<i>Figure 7.</i>	<i>IGBT Drive Waveform (+15V/-10V)</i>	<i>Fig07.eps</i>
<i>Figure 8.</i>	<i>GGT-10, Contactor Side</i>	<i>Fig08.eps</i>
<i>Figure 9.</i>	<i>GGT-10, Control Side</i>	<i>Fig09.eps</i>
<i>Figure 10.</i>	<i>GGT-10, Output Drivers</i>	<i>Fig10.eps</i>
<i>Figure 11.</i>	<i>GGT-10, Block Diagram</i>	<i>Fig11.gif</i>
<i>Figure 12.</i>	<i>Board 93, Switching Control</i>	<i>Fig12.gif</i>
<i>Figure 13.</i>	<i>Board 131, Phase Control &amp; Protection</i>	<i>Fig13.gif</i>
<i>Figure 14.</i>	<i>SCR Driver Waveform 38.4 KHz Burst</i>	<i>Fig14.eps</i>
<i>Figure 15.</i>	<i>SCR Drive Waveform Sequence</i>	<i>Fig15.eps</i>
<i>Figure 16.</i>	<i>Power Cable, Military Plug, Transmitter end</i>	<i>Fig16.gif</i>
<i>Figure 17.</i>	<i>Power Cable Phase Diagrams</i>	<i>Fig17.eps</i>
<i>Figure 18.</i>	<i>Front Panel Lamp Functions</i>	<i>Fig18.gif</i>
<i>Figure 19.</i>	<i>GGT-10, SCR Wiring Diagram</i>	<i>Fig19.eps</i>
<i>Figure 20.</i>	<i>IGBT Heat Sink Wiring Diagram</i>	<i>Fig20.eps</i>
<i>Addendum</i>	<i>Power Supply Data Sheet</i>	<i>PsPg.pdf</i>

## 1. INTRODUCTION

This manual is intended to provide the information necessary to operate the GGT-10 Transmitter and keep it in proper operating condition. It also provides the information necessary to repair the most common transmitter problems.

**Section 2** deals with the specifications for the GGT-10 and presents the curves for safe areas of operation. These curves should be observed at all times since operation outside these areas causes immediate component damage.

**Section 3** deals with the instructions and procedures needed to operate the GGT-10 in the field.

**Section 4** covers the theory of operation of the GGT-10 and contains valuable information should troubleshooting become necessary.

**Section 5** covers information necessary to troubleshoot the GGT-10 properly in the field. The troubleshooting and repair steps cover those that are possible in the field. The intent of this guide is to provide the operator with a set of explicit instructions for testing the major features of each board. The operator can determine if repair in the field is possible, if specific boards or modules must be replaced, or if the GGT-10 must be returned to a Zonge service center.

## 2. GGT-10 SPECIFICATIONS

### 2.1. Electrical

Input: 120/208 Volts 3-phase 400-cycle

All input power goes through a 3-phase contactor for power control.

Standby Power: 25 VA

Power connector: MIL SPEC Screw type

### GGT-10 Output Table

<u>Control Range</u>	<u>Current Settings</u>	
	<u>Frequency Domain</u>	<u>Time Domain</u>
650- 1000V	0.2-6.0 amp	0.2 - 10 amp
400- 750V	0.2-8.0 amp	0.2 - 13 amp
150- 500V	0.2-12. amp	0.2 - 20 amp
50- 250V	0.2-25. amp	0.2 - 25 amp

This chart is for DC to 10 KHz output frequency, using time or frequency domain and pulse EM waveform. Refer to Figure 1 for safe range operating curves.

### 2.2. Mechanical

#### GGT-10

Weight: 126 lbs., (57 Kg)

Case: L21 x W22 x H16 inches (L53.3 x W55.9 x H40.6 cm)

Case Construction: Fiberglass. All high voltage components are physically isolated from the low voltage components and wiring. The heat sink is re-mountable and replaceable as a module.

### 2.3. Electronics

Solid state electronics are incorporated for control and protection circuits. There are separate gate drive cards for each output device, with protection sensing. All drive modules for the output switch are interchangeable.

Overcurrent sense and shut down is present at each output device. All connections between the high voltage section and control section are isolated by fiber optic links, isolation transformers, and industrial grade isolation amplifiers.

## **2.4. Front Panel Controls**

Meters: Digital LCD and Analog

Input Voltage Meters (Analog): 0 to 150 volts

Output Voltage (Analog): 0 to 1000 volts

Output Current (Digital): 0 to 199.99 amps

## **2.5. Controls**

POWER ON/OFF, TRANSMIT/RESET. The main AC contactor will open for fault conditions, isolating the equipment in case of an emergency. When going to transmit, the contactor closes, and power will ramp up to preset level.

Voltage taps: 1000, 750, 500, and 250. These are chosen for best efficiency for ground loading. Output current is adjustable from .2 to 100 percent of full scale. See output table, Section 2.1.

Current range is adjusted with a 10-turn potentiometer.

## **2.6. External Control**

Frequency and duty cycle are controlled by an external controller. A 20ma current loop is used to control the logic. It is isolated from the rest of the system by a fiber optic link connecting the input plug to the control board.

The controller manufactured by Zonge International is capable of time or frequency domain operation. In time domain, duty cycles of 50% may be selected. In frequency domain, any 24 consecutive, binary-interval frequencies in the range of 1/1024 Hz to 8192 Hz may be selected. The controller is isolated from the transmitter by an optical coupler link. Custom controller units, which will match the transmitter to most other well-known geophysical systems, can be supplied with the transmitter.

## 3. OPERATING INSTRUCTIONS

### 3.1. First Time Operation

#### 3.1.1. Inspection

Inspect the transmitter for any damage that may have occurred during shipment. Remove the transmitter from its case and inspect the printed circuit cards for damage. Also check for connectors and cables that may have become loose during shipment. If any damage has occurred, it should be reported to the shipper and to Zonge International immediately and corrected before operation is attempted.

#### 3.1.2. Preparatory Set-up

Set the controls as follows:

CONTROL POWER	OFF
OUTPUT VOLTAGE	250 VOLTS
CURRENT SET	0

Connect a 100 ohm resistive load (dummy load - Zonge International Model #LB2500) to the red and black output jacks on the transmitter.

Connect a 3-phase power source (120/208 volts - 400 Hz) to the transmitter power input. (See Section 3.2 for operation of the ZMG-series motor generators.) The pins on this connector are labeled A, B, C, and D. D is the neutral input. Pins A, B, and C are the A-phase, B-phase, and C-phase respectively. C lags B by 120 degrees, and B lags A by 120 degrees. This is important for proper operation of the GGT-10. If in doubt, refer to the APPENDIX: Checking Phase Sequence - Alternator.

Connect a battery-powered or line isolated oscilloscope to the CAL output jacks on the transmitter. CAUTION: FAILURE TO USE AN ISOLATED OSCILLOSCOPE CAN CAUSE A SHOCK HAZARD TO THE OPERATOR AND MAY DAMAGE THE OSCILLOSCOPE. Set up the oscilloscope as follows:

0.5 mSec/division  
0.5 volt/division

Use external timing if available and a frequency of 1 Hz, or connect a transmitter controller to external control (XMT-32 or GDP-32) and set the frequency to 8 Hz and frequency domain.

Turn on CONTROL POWER. The green power indicator should be on. All lamps should light with the automatic lamp test. Toggle the TRANSMIT/RESET switch to RESET. All fault indicator lights should be off except for END REG. If not, the transmitter has been damaged in shipment and the failure should be reported to Zonge International for corrective action. To test for burned out or damaged lights, turn off control power and turn back on again. This will cause all lamps to turn on.

Replace any burned-out bulbs by unscrewing the lens and placing a new bulb in the socket. All lamps are 5-volt bulbs except for the 24-volt TRANSMIT lamp.



Toggle the TRANSMIT/RESET switch to RESET and then immediately to TRANSMIT. See Section 3.3.1. Do not hold TRANSMIT in the TRANSMIT position. Release the switch immediately after going to TRANSMIT. Adjust the current control knob to 2 amps output current.

The FREQUENCY/TIME DOMAIN switch on the transmitter controller can be toggled between either position. The oscilloscope trace should look as in Figure 2. Note: Do not toggle this switch when transmitting, when the DIPOLE/LOOP switch is on LOOP, or the fuse will blow on the loop-switch circuitry.

If the transmitter fails to operate properly contact Zonge International for possible corrective action.

### **3.2. Motor-Generator Hook-up Procedure (ZMG-Series)**

Disconnect the motor-generator (MG) trailer from the towing vehicle and level the unit as much as possible to permit normal oil circulation in the motor. Skid-mounted MG sets should be placed on level ground.

Remove the motor tarp and generator cover.

Check the oil level with the dipstick. Add oil if necessary.

Check the belt tension (belts should deflect at least 1 to 2 inches [2 to 5 cm] at the center of the belt but should not deflect over 4 inches [10 cm]).

Check all nuts, bolts and wires visually. Tighten any loose components.

Place the voltage regulator (VR) on the ground on the generator cover (for electrical protection of the VR). Connect the VR to the alternator using the proper cable. Place the VR out of the way and in the shade if possible. Under the trailer is a good place: it can't be tripped over, is in the shade, and will be convenient to operate. Make sure the VR is turned off.

Connect the power cable between the MG and the transmitter. Route the cable on the ground, out of standing water, and out of the way. It is not recommended procedure to leave the cable where it can be tripped over. When tightening the military-style connectors, screw the threaded sleeve until it is tight, then push and wiggle the connector to confirm the sleeve is as tight as possible. Do this with the connector on the GGT-10 as well as the connector on the MG.

Once the MG has been checked out it may be started. To start the engine (if the motor is cold), pull the choke out from the control panel. Turn the ON-START switch to START. The electric starter should crank the motor and it should start within 30 seconds. If it doesn't, refer to the appropriate manufacturer's literature. Once the motor has started, allow it to idle for about five minutes. The choke should only be needed for a few seconds unless the weather is very cold or damp.

Once the ZMG is warmed up, the engine speed can be increased to approximately 3600 RPM, by pulling the throttle lever to the right, and the alternator may be put into use. Refer to the VR MANUAL for complete instructions and troubleshooting procedures.

Turn the voltage regulator on and depress the START button on the voltage regulator, holding it down MOMENTARILY until the alternator is working. Holding the button down too long can damage the alternator, the alternator cooling fans, the GGT cooling fans, or VR circuitry.

Confirm that the cooling fan on the alternator is running. Operation under heavy load without the cooling fan will damage the alternator rapidly by overheating it.

Adjust the engine speed to produce an AC frequency between 400 and 425 Hz. Adjust the VOLTAGE ADJUST for 120 volts. See the VOLTAGE REGULATOR MANUAL for complete instructions.

### **3.3. Description of Controls**

Refer to Figure 3 for the following description of controls.

#### **3.3.1. RESET / TRANSMIT switch**

The RESET/TRANSMIT switch resets all of the internal circuitry in the GGT-10. The GGT-10 cannot transmit until a valid RESET is given. After RESET is activated the operator has a two second time-out period during which a valid TRANSMIT can be given. If TRANSMIT is not activated during this two second period another RESET must be given. This ensures proper sequencing of the internal circuitry.

#### **3.3.2. TRANSMIT light**

The TRANSMIT light being ON indicates that the GGT-10 is transmitting and that high voltage is present on the output. It is connected across the safety power contactor, and will go off when a fault or reset occurs which opens the contactor.

#### **3.3.3. SUPPLY OVERVOLTAGE light**

The SUPPLY OVERVOLTAGE light being ON indicates that the voltage level on the supply to the output switch has exceeded the safe operating level of 1000 volts. This can be caused by driving a large capacitive load, or by running with an input voltage from the alternator of more than 120 volts while using the 1000 volt tap on the TRANSFORMER OUTPUT VOLTAGE switch.

#### **3.3.4. OUTPUT OVERVOLTAGE light**

The OUTPUT OVERVOLTAGE light being ON indicates that the voltage level on the output has exceeded 1000 volts. This can indicate that a largely inductive load is present on the output.

#### **3.3.5. Status lights**

The INPUT VOLTAGE light being ON indicates that the voltage level from the alternator exceeded 130 volts or was less than 95 volts, and must be adjusted into the proper range, preferably 120 volts.

The OPEN CIRCUIT light being ON indicates that the output circuit is open and the transmitter is trying to transmit into an infinite load. NOTE: do not set the current pot to

zero as transmitter will not start.

### **3.3.6. CURRENT lights**

The INPUT OVERCURRENT light indicates that too much current has been requested from the supply generator. The detection level is 27 amps and is set at the factory.

The OUTPUT OVERCURRENT light indicates an overcurrent condition in one of the output IGBT modules. If this lamp will not reset, it indicates that an IGBT module has been damaged. Please refer to the troubleshooting section. The detection level is set at desaturation of the IGBT's. It is not adjustable.

### **3.3.7. END REG. light**

The END REG. light being ON indicates that the transmitter is not able to supply the amount of current desired. Either the current must be lowered or the TRANSFORMER OUTPUT VOLTAGE tap switch must be set to a higher voltage. It will also come on when the output current is set too low, showing an unregulated condition.

### **3.3.8. OVERTEMP light**

The OVERTEMP light indicates that a temperature of 85 deg.C has been reached on the phase control SCR's. Please shut down and allow the transmitter to cool.

### **3.3.9. TRANSFORMER OUTPUT VOLTAGE tap switch**

The TRANSFORMER OUTPUT VOLTAGE tap switch selects the output voltage range of the transformer and sets operation over the range described in the Output Table in Section 2.1.

### **3.3.10. LOGIC SUPPLY circuit breaker**

The LOGIC SUPPLY circuit breaker is a push-to-reset circuit breaker for the logic power supply (+5, +12, -12). If the button is held down during an overcurrent situation, the breaker will still open. This is a safety feature.

### **3.3.11. DRIVE SUPPLY circuit breaker**

The DRIVE SUPPLY circuit breaker is a push-to-reset circuit breaker for the four drive power supplies for the IGBT drive modules.

### **3.3.12. DIPOLE/LOOP Switch**

This switch is used to turn the loop damping circuits on and off. It should be in LOOP position only for TEM operation. Do not switch while the transmitter is transmitting.

### **3.3.13. METER SELECT switch**

This push button selects the following meter functions.

- A. OUTPUT CURRENT - Displays output current from 10 ma to 25 amps.
- B. DECAY TIME - in microseconds, time for transmitter to turn off into a loop.
- C. TEMPERATURE - in degrees Celsius - Transformer temperature.
- D. INPUT POWER - Input power to transmitter in Kilowatts, from motor generator. Use to adjust output power to match size of generator.

## **4. THEORY OF OPERATION**

### **4.1. Board 204**

Board 204 is illustrated in figures 4, 5, and 19. Board 204 accepts drive control signals from Board 93 and uses these to control the turn-on and turn-off of the IGBT's. Each board has its own transformer and power supply (the ground on Board 204 is connected to the emitter of the IGBT and needs to be isolated during operation). This board has a dual supply that generates +15 and -10 volts for the M57959L IGBT driver chip that provides drive and protection to the IGBT module. It generates a fault condition if the IGBT comes out of saturation during a current fault. There is a pair of fiber optic devices, a transmitter and a receiver to control the drive module switching and fault generation. These provide for high voltage isolation between the four drive boards, and all four must be isolated from each other for proper transmitter operation.

### **4.2. Board 93**

A test switch is located on this board for ease of troubleshooting, as shown in figure 12. This switch must be in the RUN position for normal operation. When in a test position, this switch provides either a 1 Hz or 256 Hz drive signal.

When RESET is activated, one of the 4538 ICs generates a two-microsecond reset pulse that goes to all the protection latches. RESET also goes to a second 4538 that is used as a two-second timer. The purpose of this circuitry is to ensure that the transmitter cannot be made to transmit before a valid RESET is generated. After RESET is activated the operator has two seconds to activate TRANSMIT. If TRANSMIT is not activated within two seconds then another RESET is required to initiate transmitting.

When TRANSMIT is activated during the two-second time-out, one half of a 74C74 latches the contactor relay driver (DS3631). A fault condition will reset the contactor latch and remove power from the transformer and drive to the IGBT's.

The deadtime circuitry is set for a two microsecond deadtime that is used to gate-out overcurrent detection during switching. It is generated by a 4520, 74C74, and a 1 MHz oscillator. One half of the 4520 is held in a reset state while the other half is counting. When reset on the 4520 is removed it counts two oscillator cycles before triggering one

half of the 74C74, and causes a drive signal to be generated. Loss of the oscillator prevents the drive signal from being generated.

Overcurrent is latched on this board. The fiber optic signal for overcurrent is active-low or off. This ensures that the loss of a cable will protect the drive cards and prevent drive signals from being generated. Four latched indicators are included on the board to help determine the exact source of the overcurrent situation. These correspond to the IGBT modules on the heat sink.

Overvoltage is latched on this board and the signal is active-high or on.

### **4.3. Board 131**

Board 131, figure 13, regulates the output current of the transmitter. The board provides the drive to the controlled bridge rectifier, feedback control of the bridge, plus inhibit and protection functions during faults. Its main function is to maintain a constant current at the output of the transmitter for varying loads.

Due to the harmonic noise generated by the phase control of the output voltage, the primary waveform from the alternator is distorted from a pure sine wave. To minimize the noise on the reference signal, an active filter is used to remove the higher harmonics. The active filter is set for a phase shift of 60 degrees at 400 Hz. This is compensated in the control circuitry. The filter provides the reference waveform for all of the control circuits. The output of the filter is sent to the phase lock loop.

The phase lock loop circuit (4046) is used to multiply the 400 Hz signal to a higher value that is then divided by two divider chains: one divides by 768 and the other divides by 128. These give outputs of 400 Hz and 2400 Hz respectively from a master frequency of 307.2 KHz. The 2400 Hz signal is used by the ring counter to clock the data that comes from the main comparator. This provides the equidistant pulses used to fire the controlled bridge SCRs. The 400 Hz output of the other divider chain is fed back to the 4046 phase lock loop. This phase reference is compared with the input waveform, keeping the multiplied signal phase locked to the input frequency. Due to the large capture ratio of the system, the phase locked loop can remain in lock over a large range of frequencies. After power up on the system, it may take a second or so for the phase lock loop to lock in. After it locks in, it should remain so for all conditions except a complete loss of power.

The main comparator provides updated information on the output current to the firing circuits. It provides the reset pulses for the ring counter. The comparator switches its output in reference to the DC level of the control voltage as compared to the full wave rectified sine wave. The switching point provides the timing for the firing angle of the SCRs. Maximum firing angle is reached when the control voltage is equal to the peak of the reference sine wave, while the converse is true when the control voltage is at zero. During normal regulation, the control voltage will increase and decrease as needed to maintain a constant output current.

The next section covers the control and protection circuitry of Board 131. There are two divisions to this section, one which covers the current feedback loop and the other which provides protection from faults in the system.

### **4.3.1. Current Regulation**

This is composed of the following sections: current setpoint, slow turn-on, isolated current sensing, and integration of the current setpoint with current feedback.

#### **4.3.1.1. Current Setpoint**

Current control is accomplished by sensing a control voltage that is buffered by an amplifier controlling the offset of the integrator's negative input. This voltage sets the point at which the integrator output is equal to the voltage required to maintain a steady state current in the feedback loop.

#### **4.3.1.2. Current Feedback**

The transmitted current is sensed across a 0.1 ohm resistor and then sent through a true RMS (Root Mean Square) device (AD536), a sample-hold device and an isolation amplifier. This provides a DC representation of the output with noise and ripple being averaged out. The output of the isolation amplifier is sent to both the integrator and the digital voltage meter through buffer amplifiers.

### **4.3.2. Transmit, Soft Turn-on**

Two other devices tie onto the positive integrator summing junction. These are used in transmitter turn-on and fault control. Soft turn-on is provided by the 74C908. The integrator is held in an off condition until turn-on. Due to the integration time constant, power is applied at a controlled rate. Also, the 74C908 forces the positive input of the integrator to be high in a fault or rest condition.

### **4.3.3. Fault Detection**

The board can sense various out-of-range levels and act accordingly. There are provisions for alternator undervoltage and overvoltage, end of regulation, open circuit, and input overcurrent.

Alternator under/overvoltage is sensed by the true RMS converter and scaled to be proportional to the input voltage. If it exceeds the preset value, the alternator overvoltage lamp will light and the board will shut down until the voltage reaches a safe value. This is not a latched condition.

End-of-regulation also uses the alternator voltage and senses when there is not enough voltage to maintain regulation by comparing the alternator voltage to the control voltage. A lamp will light for this condition but no shutdown takes place. Input overcurrent sensing is provided to detect overcurrent on the input supply. This is accomplished by sensing the input supply current through a current transformer, converting this to the RMS value of the input current, and then applying the DC signal to a comparator that is set to trip when the current exceeds 27 amps on the supply A-phase. This resets the transmitter switch shutting off the transmitter.

Open Circuit detection also uses this circuitry to detect when the transmitter should be transmitting but no current is being output. Both circuits latch and indicate their condition on front panel lamps.

#### **4.4. Board 99 - Output Pulse Amplifiers DANGER - HIGH VOLTAGE**

Board 99 contains the pulse amplifiers and transformers. While inhibit is high, the gate drive will output to the drive amplifiers with the modulation signal impressed on it. This signal drives the 2N5335 transistors that drive the pulse transformers. The pulse transformers drive the SCRs and provide isolation between the SCRs and the control board. By using high frequency modulation, an efficient transformer can be used and a lower average current in the pulse transistors is maintained.

#### **4.5. Boards 175, 176 - Meter Circuits**

The current meter also has different functions that receive signals from Board 131. The input power is measured and calculated with a multiplier circuit AD633 from the input current and input voltage. These values are the true RMS values used for input overcurrent and input voltage. The voltage along with the output current and the digital period and duty cycle are sent to the meter Boards 175 and 176.

### **5. TROUBLE-SHOOTING PROCEDURES**

#### **5.1. High Voltage Areas, Board 99 SCR's, Heat sink IGBT's**

Dangerous voltages are present throughout the transmitter. The following is a list of most but not all of the areas where caution must be exercised. See figures 17, 19 and 20.

3-phase 120 VAC input at the contactor, line fuses, power supply, Board 99, high-voltage transformer, and IGBT drive transformers.

All heat sinks, which can vary from ground potential to 1000 volts.

All boards numbered 204. These float along with the transmitter output and can have 1000 volts at whatever frequency is being transmitted.

The voltage-tap switch, phase-control SCR's, filter choke, supply capacitors, protection choke, and protection diode.

The metal chassis is connected to the AC generator neutral line and should not carry high voltage under normal operating conditions. However, for safety, it is normal to ground the transmitter chassis to a stake well away from any transmitter electrodes.

All four output terminals are naturally dangerous at all times. When the transmitter is turned off, it takes approximately five seconds for the bleeder resistor to discharge the capacitor completely. It is good practice to touch only one output terminal at a time while keeping your other hand in your back pocket, even when the transmitter is turned off.

#### **5.2. Disassembly**

The GGT-10 can be removed from its case by removing the six screws along the outer edge of the panel. The unit must be removed to gain access to the heat sink module on which the IGBT transistors are mounted. This unit must also be removed when it is

necessary to change the primary fuses located below the AC input. Caution should be exercised when removing or installing the panel in the case as all components are mounted to the front panel. The GGT-10 should never be operated out of the case for any length of time at frequencies above 256 Hz because proper cooling will not occur.

### **5.3. Heat Sink Removal**

The output heat sink may be removed from the case to facilitate replacement of the IGBT's. Remove the two #8 screws on the outside edge of the heat sink panel. There is one on the rear of the transmitter and one in the front under the right edge - see GGT-10 Heat sink side, figure 10

### **5.4. Board 204 - INSULATED GATE BIPOLAR TRANSISTOR Drive**

Board 204, figures 4, 5, and 17, can be tested by connecting a 120/208 VAC-400 Hz motor generator to the transmitter input military connector. Pin A is the A-phase input and provides power for the internal power supplies on these boards. Pin D is the transmitter neutral. Disconnect the external control source as the internal timing is used for most of the tests on this board. Disconnect the contactor relay by disconnecting the molex plug connected to the single yellow wire at Board 93. NOTE: IT IS VERY IMPORTANT THAT THE CONTACTOR BE DISCONNECTED SO THAT HIGH VOLTAGE WILL NOT BE PRESENT ON THE IGBT MODULE DURING TESTING. Follow the procedure below to determine if the fault lies with this board or with some other part in the transmitter. NOTE: ALL RESISTANCE MEASUREMENTS SHOULD BE MADE WITH THE TRANSMITTER TURNED OFF.

**5.4.1.** Verify first that Board 93 is working. Its proper operation is essential to proper operation of these IGBT drive boards. See Section 5.5.

**5.4.2.** A fault light that cannot be RESET is a good indication of an IGBT or Board 204 failure. Disconnect the molex connector lead to the IGBT module suspected to be failing and then follow the procedure below using a Fluke or similar digital voltmeter. The "from" point uses the ground lead on the Fluke and the "to" point uses the positive lead of the Fluke. All resistance measurements are made with the transmitter turned OFF.

**5.4.3.** Measure the resistance from emitter to collector of the IGBT. See figure 5. The test point is the disconnected molex connector. This reading should be approximately 500 ohms, with a high-value diode function meter. Using other meters with low ohms the value may be 30K-ohms or 0.35 volts in diode mode. If not, go to Section 5.4.9.

**5.4.4.** Measure the resistance from collector to emitter. This reading should be infinite. If not, go to Section 5.4.9.



**NOTE - THE FOLLOWING SHOULD BE DONE ONLY IN A NON STATIC ENVIRONMENT**

**GATES ARE SENSITIVE TO STATIC ELECTRICITY**

**5.4.5.** Measure the resistance from gate to collector and from gate to emitter. The gate test point is the molex connector. These readings should be infinite. If not, go to Section 5.4.9.

**5.4.6.** Measure the resistance from collector to gate. This reading should be infinite. If this reading indicates a short, or other resistance, go to Section 5.4.9.

**5.4.7.** Measure the resistance from emitter to gate. This reading should be infinite. If this reading indicates a short, or other resistance, go to Section 5.4.9.

**5.4.8.** If the IGBT has tested okay, go to Section 5.4.11 to test Board 204.

**5.4.9.** Replace the IGBT. Disconnect the gate leads at Board 204 by disconnecting the molex connector. See figure 5. Remove the two screws in the base of the IGBT and remove it from the heat sink. Reverse this process to install the replacement IGBT. Avoid excessive torque on the two screws in the base of the IGBT to prevent stripping these holes. The IGBT module is equivalent of two IGBT's and two diodes. Be very careful to connect gate leads to proper connections on the module.

**5.4.10.** Whenever an IGBT fails it is possible that another one has also failed. Check the other IGBT's using the previous procedure. Next, it is essential to test the quenching diode, DD31S-1400, around the protection inductor on the heat sink module. If this diode has shorted, then the overcurrent protection will not work and more IGBT's will be lost if another short occurs. If this diode has opened, then the output will be unstable and will cause either OVERVOLTAGE indications or IGBT failure. Test this diode by removing its cathode lead and measuring it with a Fluke or similar digital voltmeter on the lowest diode, range (2K). The anode to cathode resistance should be infinite. Cathode to anode should be in the range of 500 - 800 ohms. If the diode is bad, replace it. Test all the quenching diodes using the previous procedure.

**5.4.11.** Turn on the transmitter. Reset the transmit switch and make sure all lamps are out. Check for -10 volts between gate lead and emitter on Board 204's. If present go to Section 5.4.13. If not present then continue with Section 5.4.12.

**5.4.12.** Check the circuit breaker. If it has tripped then reset it and recheck for 120 VAC input at each module. If 120 VAC is still not present then check for wiring problems or problems with the power source. Correct the problem and go to 5.4.13. If the modules continue to trip the circuit breaker, determine the module that is responsible and replace it.

**5.4.13.** Check that the +15 volt supply at the output of the 340-15 is within 1/2 volt of 15 volts. If this supply is within this limit, go to 5.4.16.

**5.4.14.** Check the input to the positive regulator (340-15) from the bridge rectifier. This should be approximately +20 volts but will vary according to the input source voltage. If the input is not +20 volts, check D2, C4 and the output of the transformer. Correct the problem and go to 5.4.13.

**5.4.15.** If the input to the regulator is correct but the output is not, check the drive device for shorts (57959) or the five-volt regulator. Correct the problem and go to 5.4.13.

**5.4.16.** Check the -10 volt supply at the output of the negative regulator (337). This should be within 1/2 volt of 10 volts. If this supply is within these limits, go to 5.4.19.

**5.4.17.** Check the input to the negative regulator (337) from the bridge rectifier. This should be approximately -20 volts but will vary according to the input source voltage. If the input is not -20 volts, check D5, C8 and the output of the transformer. Correct the problem and go to 5.4.16.

**5.4.18.** If the input to the regulator is correct but the output is not, then check the regulator and the IC (57959) for a failure. Correct the problem and go to 5.4.16.

**5.4.19.** Check the 5-volt regulator (78L05). Use the ground reference. If the regulator is putting out 5 volts +/- .5 volts, go to 5.4.20. If the regulator is failing, replace it and recheck the output. If it still appears to be failing, then the optical receiver that it is supplying is bad and must be replaced.

**5.4.20.** Plug in all of the cables to the IGBT drive modules and set the test switch on Board 93 for a 256 Hz test signal. Then activate the RESET switch on the transmitter after applying power to the unit. All of the fault lights should be OUT. If not, go to 5.4.2 before proceeding any further. The fault light will indicate a failing module but others may also be failing and can be checked by performing this same procedure, starting at 5.4.2.

**5.4.21.** Reconnect the leads between Board 204 and the IGBT heat sink modules as in figure 20. The output should look like figure 7 on all modules. If not, recheck step 5.4.21. If the problem is still present go back to 5.4.2 and recheck the IGBT. If the output agrees with figure 7, Board 204 is working properly. Turn the transmitter OFF and check diode D4 using a Fluke meter on the diode range. Replace the diode if it is open or shorted. It is recommended to test D4 in this manner because testing it while transmitting without the proper high voltage probe can be hazardous to the operator.

**5.4.22.** Recheck the power supplies (+15, -10, +5 volts) using steps 5.4.13 to 5.4.19. Correct any power supply problems. Set the test switch on Board 93 to 256 Hz.

**5.4.23.** Connect the scope ground lead to the IGBT emitter. Connect the scope probe to the 57959 IC cathode. A 256 Hz signal between +5 volts and not quite ground should be visible. If present, go to 5.4.26. If this is not present, check the fiber

optic DRIVE cable from Board 93. The light output should be RED. Move the test switch on Board 93 to the 1 Hz position. Now the drive signal should alternate ON and OFF at a 1 Hz rate. If there is no drive signal and no fault lights are on, repair Board 93. Board 93 will not produce drive signals when faults are indicated. If fault lights are ON and RESET does not clear the fault, go to the troubleshooting procedure for Board 93. If the fiber optic drive is working and the signal at the output of fiber optic is incorrect as tested above, continue on.

**5.4.24.** NOTE: the IGBT devices will output an overcurrent fault whenever they are disconnected from Board 204. This makes the bad module a little more difficult to determine. The best method is still to replace any module that seems to vary in tests from a new one.

**5.4.25.** Observe the light output of the gray optical transmitter. When the IGBT module is connected to Board 204, the light should be ON, and when disconnected it should be dim and flashing at a high rate. If it does this, the current sense circuitry is working properly. Go to 5.4.20 and recheck.

## **5.5. Board 93 - Output Switch Control**

Board 93, figure 12, can be tested by connecting the transmitter to a motor generator. Pin A is the A-phase input and provides power for the internal power supplies for this board and the IGBT driver modules. Pin D is the transmitter neutral and is connected internally to the transmitter chassis. Therefore, an isolation transformer is needed on the oscilloscope. Disconnect the external drive source, as the internal timing is used for most of the tests on this board. Disconnect the contactor relay by disconnecting the molex plug by the contactor. NOTE: IT IS VERY IMPORTANT THAT THE CONTACTOR BE DISCONNECTED SO THAT HIGH VOLTAGE WILL NOT BE PRESENT ON THE OUTPUT DURING TESTING. Follow the procedure below to determine if the fault lies with this board or with some other part in the transmitter. NOTE: ALL RESISTANCE MEASUREMENTS SHOULD BE MADE WITH THE TRANSMITTER TURNED OFF. Check SV power to board.

**5.5.1.** Push "RESET".

**5.5.2.** If the OVERVOLTAGE lights are still on, go to Section 5.5.15.

**5.5.3.** If the OVERCURRENT lights are still on, go to Section 5.5.17.

**5.5.4.** Set the test switch on this board to the 1 Hz position and pull all of the fiber-optic cables labeled DRIVE. See figure 12. These connectors are gray. Observe the lights (LEDs) in the four optical drivers. DRIVE1 and DRIVE2 should be alternating with DRIVE3 and DRIVE4 at 1 Hz. If this is not occurring, go to Section 5.5.8.

**5.5.5.** Set the test switch to the RUN position and attach the external controller. Set the frequency to 1 Hz and again observe the output from the four optical drivers. If they do not alternate, go to Section 5.5.7.

**5.5.6.** Reinstall the four drive cables. This board has tested O.K. Go to Section 5.5.15.

**5.5.7.** Check the fiber optic cables from the drive input Board 91 to Board 93 to ensure that all cables are installed properly. If this does not correct the problem, pull the TRANSMITTER DRIVE cable from Board 93 and observe the output from the cable. The light should be alternating ON and OFF. If it is not, the external controller may be off or malfunctioning, or the input optical driver may be bad. If the output of the cable is alternating ON and OFF, then either the optical receiver is bad or IC C3 is bad. Correct the problem and go to Section 5.5.5.

**5.5.8.** Use an oscilloscope to check for a 1 MHz square wave at pin 1 of IC B5. If there is no signal here, check the five-volt supply to this board and be sure power is ON. If power is ON and five volts is absent, check the power supply and replace it if necessary. If five volts is present, replace the oscillator and go to Section 5.5.4.

**5.5.9.** Check for a 1 Hz drive signal on pins 7 and 15 of IC B5 (4520). If this is not present, make sure that the test switch is in the 4 Hz position. If the 4 Hz drive signal is not present, IC C3 or C4 is bad. Replace the faulty IC, check the drive signal, and go to Section 5.5.4.

**5.5.10.** Set the test switch to 1 KHz. A 1 KHz square wave should be present at pins 3 and 11 of IC B4. If this square wave is not present, IC B5 is bad and must be replaced. Replace IC B5, check the square wave again, and go to Section 5.5.4.

**5.5.11.** Check for a 1 KHz square wave at pins 5 and 9 of IC B3. If this is not present, replace IC B4 and go to Section 5.5.4.

**5.5.12.** Check for a 1 KHz square wave at the output of IC B3. If this is not present, look at the levels on the following pins. Pins 1, 2, 4, 10, 12, and 13 should all be at five volts. If they are not, check for fault lights being ON, five-volt power supply failure, IC C3 failure or Duty Cycle optical receiver failure. Correct the failure and go to Section 5.5.4.

**5.5.13.** Check for a 1 KHz square wave at pins 3 and 5 of IC B2. If this is not present, either B2 is bad or the optical drivers are bad. Determine which is failing and replace.

**5.5.14.** Check for an active drive signal light at the output of the optical drivers. If present, go to Section 5.5.15. If not, go back to Section 5.5.8 and recheck the signals.

**5.5.15.** Pull all four of the OVERCURRENT cables from the blue optical receivers labeled PROT1, PROT2, PROT3, and PROT4. This should cause the OVERCURRENT fault lights to come ON. Now reinstall the four OVERCURRENT cables and push the RESET switch and observe the fault lights. If the OVERCURRENT fault lights reset, go to Section 5.6. If not, then IC D9 or the OVERVOLTAGE optical

receiver is bad; correct this problem and go to Section 5.5.1. If the OVERCURRENT fault lights stay ON, go to Section 5.5.16.

**5.5.16.** The tests indicate that either IC D4, or the RESET switch, or wiring is bad. Correct the problem with the RESET circuitry and go to Section 5.5.1.

**5.5.17.** Pull the OVERCURRENT fault cable associated with the fault light that cannot be reset. If the end of the cable glows RED, go to Section 5.5.19.

**5.5.18.** The IGBT module (Board 204) associated with the unlit cable is failing or has its cable unplugged. Repair the module or plug in the cable and go to Section 5.5.1.

**5.5.19.** Pull the other OVERCURRENT cables. The OVERCURRENT fault lights should come ON. Reinstall the cables and activate the RESET switch. If the OVERCURRENT lights associated with the cables that were pulled do not go OUT, go to Section 5.5.16.

**5.5.20.** Check the IC's associated with the fault light that cannot be reset, which will be either C7, D7, C6, C8 and C9 and the optical receiver associated with the fault light. Repair the problem and go to Section 5.5.1.

## **5.6. Board 131 - Current Feedback and SCR Drive Signals**

Board 131, figure 13, can be tested by connecting the transmitter to a 120/208 VAC-400 Hz motor generator. Pin A is the A-phase input and provides power for this board. Pin D is the transmitter neutral. Disconnect the external drive source, as the internal timing is used for most of the tests on this board. Disconnect the contactor relay by disconnecting the molex plug at Board 93. NOTE: IT IS VERY IMPORTANT THAT THE CONTACTOR BE DISCONNECTED SO THAT HIGH VOLTAGE WILL NOT BE PRESENT ON THE IGBT MODULE DURING TESTING. Follow the procedure below to determine if the fault lies with this board or with some other part in the transmitter. NOTE: ALL RESISTANCE MEASUREMENTS SHOULD BE MADE WITH THE TRANSMITTER TURNED OFF.

### **5.6.1. Power Supply**

First, verify that the supply voltages +5 and 12 are present (see the test points on Board 131, figure 13). If they are not within +5%, unplug Board 131 and recheck the power supply. If the power supply is still not working, notify Zonge International as there are no user serviceable parts on the power supply.

### **5.6.2. Oscilloscope Setup**

Setup a Tektronix model 212 Oscilloscope or similar battery-operated or line-isolated oscilloscope as follows:

DC coupled	5.0 volt Range
1 msec/div	Channel 2 trigger
Ground lead on ground wire	

### **5.6.3. Active Filter**

Set the input voltage to 120 VAC RMS. Setup procedure for the active filter output - This adjustment must be made before any other setup or checkout procedure can be made. With the scope probe tip on the output of pin 6 of H-4 (OP-5) (see TP-0 on figure 13) adjust pot R26 for a 20 VPP (+ 1 volt) signal at pin 6 H-4.

### **5.6.4. Phase Lock Loop**

The phase lock loop (D3) is used to multiply the 400 Hz signal to get a resultant frequency of 307,200 Hz (see theory of operation). Pin 1 on D3 is the in-lock indicator. When the system is in-lock the output of pin 1 of D3 is a 5 volt level signal with a pulse 5.0 microseconds wide going to ground at 2.5 milliseconds intervals. Pin 4 should have a 307,200 Hz square wave with a period of 3.3 microseconds, and pin 3 should have a 400 Hz square wave synchronized with pin 14. The output of pin 4 is divided by A3. This results in a 2.4 KHz square wave and a 38.4 KHz signal for the gate drive to the SCR drivers. The 307,200 Hz signal is also divided by C3 (4522) and B3 (4520) to 400 Hz which is the feedback to the phase-lock loop for phase comparison with the incoming signal. There will be no output from A3 if reset is HIGH. Reset is generated by the positive-going pulse each time the comparator F4 (CMP01) switches.

### **5.6.5. Current Set Point Reference**

To check the output current set point reference G7 (LH0070) use a digital voltmeter set for DC input on the 20-volt range. Check the REF output to the current setpoint potentiometer: for a GGT-25 it should be 4.04 volts +10 mv and for a GGT-10 it should be 2.02 volts +10mv. Put the probe tip on the Set input from the current setpoint potentiometer and adjust the current set potentiometer from 0.0 to 10.0 divisions. The voltage should vary according to transmitter type from 0-4 volts or 0-2 volts. Check the output of H5 (OP5), the current set buffer, for tracking over the same range.

### **5.6.6. TRANSMIT / RESET Switch**

To check the TRANSMIT/RESET switch, put the scope probe on TEST input or pin 1 E1 (74C30). The signal will be LOW for RESET and HIGH for TRANSMIT.

Pin 9 of F3 (4038) should give a two second low pulse each time the TRANSMIT/RESET switch is toggled to TRANSMIT. This is the inhibit time for the contactor to pull in. This reduces the transient pulse that occurs when an unloaded transformer is energized.

### **5.6.7. Fault inhibit**

Pin 8 of R1 (74C30) should be LOW after two seconds when the TRANSMIT/RESET switch is toggled toward TRANSMIT, and goes high when the switch is toggled toward RESET. Pin 6 of E2 (74C00) is the inverse. This signal controls the soft-start gate and the output gate drive to the SCR bridge. If pin 6 of the E2 does not go HIGH, check the alternator over/under voltage and pin 9 of 74C221 (F3). This should be HIGH for the output of E1 (pin 9) to go LOW.

### **5.6.8. Alternator High-Low shut down**

This signal also controls the inhibit function. It is generated by the level of the AC voltage from the active filter that feeds H2 (AD536, a true RMS converter). The output should be 10 volts for a 20-volt peak-to-peak AC signal. This is the reference for the transmitter alternator shut-down comparators. G1 and H1 should be HIGH if they are in tolerance for correct alternator input voltage (see setup procedure for correct voltages on shut down), i.e. 90 volt for low shut down and 130 volt for high shut down.

If the outputs to E1 are both HIGH but pin 6 of E2 is still LOW, check the FL-EXT.FAULT input at the lower edge of Board 100. This is the fault input from Board 93. It will also inhibit Board 100.

### **5.6.9. Soft start**

This is an open collector pull-up to inhibit the feedback integrator. By pulling up pin 3 of F5 through R 30, the integrator shuts down. Put the scope probe on pin 6 of F5 and toggle the TRANSMIT/RESET switch. The output should remain HIGH in RESET and drift negative on TRANSMIT.

### **5.6.10. Current feedback**

The output of F5 is compared to the reference waveform from the active filter by comparator F4 (CMP-01). As long as pin 6 of F5 is greater than 10 volts, there is no output from F4. As pin 6 goes more negative the output of F4 switches from 0.0 to 5.0 volts as the sinewave crosses the level of the pin 3 input. Normally the output of the isoamp drives this input which regulates the output current. In the test mode the output of the integrator will swing from +10V to -10V. As it swings, the output of the comparator (pin 7 of F4) will sweep from zero volts to a 400 Hz square wave after the two-second delay. This happens each time that the TRANSMIT/RESET switch is toggled.

The output of comparator F4 (pin 7) goes to pin 2 of F2. This is a one shot multi-vibrator (74C221). Pin 13 is the Q output which resets A3 (see the phase locked loop section). QNOT (pin 4) also triggers pin 10 of F2 which provides a low inhibit pulse of 1.6 microseconds to keep the A-half of F2 (74C221) from retriggering at the 180 degree point of the reference waveform.

Pins 4 and 8 of F2 (74C221) provide the reset pulses to the main counter A3 and the shift register D2, C2 and D1. This shifts the firing angle information through the SCR drive gates B2 and C1.

Pin 13 of F2 is compared with the 400 Hz square wave from the comparator H3 (CMP01). If the phase position of pin 13 of F2 as compared to the 400 Hz input is greater than 90 degrees, then the end of regulation light is turned ON. In test mode with the current set point at zero, the end of regulation light should extinguish momentarily two seconds after going to transmit and then come ON again. Toggle the transmitter RESET switch ON and OFF to ensure that this is happening.

### **5.6.11. SCR driver wave forms**

Look at pin 9 of A2 (88C29). As the TRANSMIT/RESET switch is toggled to TRANSMIT, a waveform as shown in figure 14 of 38.4 KHz and 0.8 milliseconds wide should be found on pins 5 and 9 of A2 and on pins 5, 6, 8, and 9 of B1. These are the SCR drive waveforms. Each waveform is shifted in time from the previous one by 0.4 milliseconds from 1 to 6 in the SCR outputs. This is the firing sequence for the SCR controlled bridge. See figure 15. The isoamp must be offset to defeat open circuit shutdown.

### **5.6.12. Duty cycle input**

With The TRANSMITTER CONTROLLER (Zonge model XMT-16 or XMT-32) connected to EXT control, set the TRANSMITTER CONTROLLER for a 256 Hz 50% duty cycle time-domain signal.

The input to Board 131 should be a 512 Hz square wave at DUTY on the upper right corner of the board. Check the duty cycle output to the isoamp. This is a buffered output from Board 131. It controls the sample-and-hold on the isoamp. Switch the TRANSMITTER CONTROLLER to 1 Hz and set the current set potentiometer to 5.00. On the GGT-10 it will be 1.0 volt at "Set". Pin 1 of F6 (IH5042) should switch between 0.0 and 1.0 volts. This checks the integrate-and-hold function for the pulse variable outputs. If there is no switching, check pin 16 of F6 for 0.0 volts and pin 4 for 1.0 volts. If pin 16 is not 0.0 but pin 3 of F7 is 0.0, this indicates a bad IH5043.

The remaining circuits are for the open circuit shutdown and input overcurrent. The two circuits work together and cause the same type of fault latch.

Input overcurrent shut-down is set by B5 CMP-01 and is adjusted for 27 amps on the input at phase A. This will be approximately: 0.51 volts D.C. at the output of the RMS converter B6-AD536. Adjust R35 until the input overcurrent lights.

Set Open Circuit shut-down: set output current to 0.200 amps on the 250 volt tap with a 100 ohm load and adjust R32 until the open circuit lamp comes ON. Reset transmit and try again. Make sure you can start transmitting when current is 0.500 amps.

## **5.7. Power Supply - See Addendum Power Supply (data sheet)**

Refer to the power supply data sheet in the back of this manual for test points and voltages. Remove the output connector before measuring the voltages. Check the input first to ensure that the circuit breaker, control power switch, and generator are O.K.

If any voltages are out-of-tolerance return the supply to Zonge International. They have no user serviceable parts and are covered by a one-year manufacturer's warranty.

## **5.8. Meter Circuits**

The meter boards can be adjusted for decay time only. All other values are factory set. The adjustments are VR1 and VR2 on Board 176. Board 176 contains an instrumentation amplifier to monitor the turnoff (INA 117), amplifier, comparator, counters, and DAC to compute and output the decay time as a voltage. This voltage is



sent to Board 175 where it is multiplexed with the other voltages, then displayed on the digital meter (7129A and display).

VR1 sets the comparator level and VR2 sets the output of the DAC. If the decay time reads too low, increase VR2. Otherwise, adjust to match a measured decay time on an oscilloscope.

## 6. APPENDIX

### 6.1. Checking Phase Sequence - Alternator

NOTE: This test should be made at the military plug on the end of the transmitter power cable that plugs into the transmitter (figure 16). This ensures that all of the wiring is correct between the alternator and the input to the transmitter.

**6.1.1.** Use a DVM (Fluke) to check the absolute voltages on each phase.

Set the Fluke to:

AC  
200 volt range

**6.1.2.** Place the ground lead of the Fluke on the neutral lead of the plug, i.e. lead "D" (figure 16). Place the positive Fluke lead on leads (phases) A, B, and C (figure 16) in turn and record the voltages for each phase. The voltages should all be within 10% of each other.

**6.1.3.** NOTE: When you measure the 3-phase voltages as indicated above, if one of the phases measures the normal 110 to 120 volts and the other two phases measure approximately 200 volts, the lead "D" is not connected to "neutral" on the alternator. If you attempt to bring up the transmitter with the alternator in this configuration, serious damage will result.

**6.1.4.** Set a Tektronix 212 or similar oscilloscope as follows:

TRIGGER SOURCE	CH2
TRIGGER LEVEL	AUTO
SEC/DIV	.5m
VOLTS (BOTH Ch1 and Ch2)	50
INPUT COUPLING	AC

**6.1.5.** Connect the ground lead on the Ch2 probe on the oscilloscope to the neutral lead (figure 16) on the military plug.

**6.1.6.** Bring up to 120 volts using the voltage regulator. **WARNING: POTENTIALLY FATAL VOLTAGES ARE NOW PRESENT ON THE OUTPUT LEADS ON THE MILITARY PLUG.**

**6.1.7.** Carefully place the Ch2 probe on pin A ("A" phase) on the military plug (figure 16). Adjust the VOLTS/DIV VAR knob to achieve a peak-to-peak signal of four divisions. Adjust the HORIZ MAG knob to achieve a peak-to-peak signal of six divisions. Adjust the horizontal POS knob to adjust the waveform as shown in figure 19.1.

**6.1.8.** The correct phase sequence is: B lags A and C lags B, both by 120 degrees. Keep the Ch2 probe on the A-phase and place the Ch1 probe on the B-phase

(figure 16). If you have the waveform on the oscilloscope such that the horizontal peak-to-peak signal is six divisions (figure 17.1), then each division is equal to 60 degrees. Therefore, the B-phase signal (Ch1) should be two divisions to the right of the A-phase (figure 17.2). If the phase sequence is not correct, the B-phase will lead the A-phase by 60 degrees (figure 17.3).

**6.1.9.** If the B-phase leads the A-phase (as shown in figure 17.3), reverse any two of the transmitter power cable leads on the alternator and repeat Section 6.1.

**6.1.10.** Keep the Ch2 probe on the A-phase and place the Ch1 probe on the C-phase. The C-phase should lag the A-phase by 240 degrees, i.e. the C-phase should be four divisions to the right of the A-phase (figure 17.4).

## **6.2. Options**

The following options may or may not be installed.

### **6.2.1. Loop Switch**

This option is used when the GGT-10 is used to drive loops or long grounded dipoles in the time domain or transient E.M. mode. It is only operational in this mode and cannot be used in Frequency Domain. When the signal that turns off the output is received, an SCR across the output is fired and a 120 ohm 50 watt resistor is connected to the loop. This provides damping for transients occurring in the loop at turnoff.

## **6.3. Transmitter Front Panel Lamp Functions**

All lights (except TRANSMIT) come on when POWER is switched on (Lamp test). RESET turns them off, except for ON and END REG. See figure 18.

- A. **Power On** The DC supplies and control circuits are powered up.
- B. **Supply** This light indicates that the high voltage supply has reached 1,000 volts. Resets transmitter. Check for excessive input voltage.
- C. **Output** This light indicates an output voltage of 1,000 volts. Resets transmitter. At the highest frequencies, loads can look inductive and cause spikes that trip this circuit. Adjust current down.
- D. **Status** This indicates that the input voltage is out of range or a possible phase loss.
- E. **Open Circuit** Output current is too low. Measure electrode resistance to check for an open circuit. Current setting may be too low.
- F. **Input Current** This input power is limited to transmitter power specifications. Resets transmitter. Possible input phase loss. Transmitter is most efficient near the top of each tap switch range.
- G. **Output Overcurrent** This indicates an overcurrent condition in the output circuit. Resets transmitter. If transmitting into a loop (very low resistance), it

may be necessary to use a dummy load in series. If the light does not reset, a GTO or GTO drive board has failed.

- H. **Reg** This light is off only when the output is regulated. Output should be regulated through the range of each tap setting. A narrow range of regulation could indicate loss of a phase, incorrect control settings, or low input voltage.
- I. **Over Temp** Temperature too high by SCR's. Let cool.
- J. **Transmit** This indicates power at the electrodes.

#### 6.4. Transmitter Display Operation

When the transmitter is turned on, the display comes up in the **Current** function. The current to the electrodes is shown in Amps.

Each time the Meter Select button is pressed the display will move to the next function.

The **Decay Time** units are micro-seconds. This is only valid when transmitting in time domain. The Decay Time in micro-seconds is the time from Transmitter Off to Current Zero. This is needed for corrections in the TEM program. See the TEM program section in the GDP manual.

The third function displayed is in degrees Celsius. If this temperature exceeds 90°C, the transmitter must be cooled by stopping transmitting and letting the fans operate unobstructed.

The last meter function is **Input Power**, shown in kilowatts. The transmitter will operate up to the rated power, per the transmitter manual and will reset.







Figure 1. Safe operating curves for GGT-10

Fig01.eps



8 Hz Frequency Domain 100 Volts / div 50 msec / div



8 Hz Time Domain 100 Volts / div 50 msec / div

50% duty cycle

Figure 2. Output Waveforms

Fig02.eps




Figure 3. GGT-10, Front Panel

Fig03.gif




Figure 4. Board 204

Fig04.gif




Figure 5. Board 204

Fig05.gif






Figure 6a: IGBT




Figure 6b: Diode




Figure 6c: SCR

Figure 6. IGBT, Diode, SCR illustrations

Fig06.gif




Figure 7. IGBT Drive Waveform (+15V/-10V)

Fig07.eps




Figure 8. GGT-10, Contactor Side

Fig08.eps




Figure 9. GGT-10, Control Side

Fig09.eps





Figure 10. GGT-10, Output Drivers

Fig10.eps



ZONGE ENGINEERING & RESEARCH ORGANIZATION			
PROJECT:	TRANSMITTER BLOCK DIAGRAM	DATE:	Tue Nov 08 1994
TITLE:	GGT-10: MAJOR BOARDS & COMPONENTS	SHEET:	1 OF 1
DESIGN:			
SIZE:	B	DWG:	GGT-10.591

Figure 11. GGT-10, Block Diagram

Fig11.gif




Figure 12. Board 93, Switching Control

Fig12.gif




Figure 13. Board 131, Phase Control & Protection

Fig13.gif




Figure 14. SCR Driver Waveform 38.4 KHz Burst

Fig14.eps




Figure 15. SCR Drive Waveform Sequence

Fig15.eps




Figure 16. Power Cable, Military Plug, Transmitter end.  
Check phases before connecting.

Fig16.gif




Figure 19.1 Adjust oscilloscope so that the A - phase waveform matches this diagram.




Figure 19.2 Correct phase relation for A and B phase.




Figure 19.3 Incorrect phase relation for A and B phase.




Figure 19.4 Correct phase relation for A and C phase.

Figure 17. Power Cable Phase Diagrams

Fig17.eps




Figure 18. Front Panel Lamp Functions

Fig18.gif






Figure 19. GGT-10, SCR Wiring Diagram

Fig19.eps





Figure 20. IGBT Heat Sink Wiring Diagram

Fig20.eps

# 40W

## OPEN-FRAME SWITCHING POWER SUPPLIES

- ✓ Single, Dual and Triple Output Models
- ✓ Universal AC-Input and DC-Input Models
- ✓ CE Mark: UL/CSA/EN60950 Approvals
- ✓ BABT Approvals
- ✓ Austel CCL Certification
- ✓ EN55022/FCC Class B Input Line Filter
- ✓ 0% Minimum Load Requirement
- ✓ Over-Current/Short-Circuit Protection
- ✓ 2-Year Warranty
- ✓ Minimum 200,000-Hour MTBF



### CHARACTERISTICS


Input Voltage .....	FLU models, universal input range 85-265 VAC single phase or 100-370 VDC. DC input models, 36-75 VDC (48V, nominal).
Input Line Frequency .....	FLU models, 47-440 Hz (50-60 Hz, nominal).
Input Line Protection .....	MOV transient protected (FLU series). Input line fuse provided on-board. (See Note 1.)
EMI Filter .....	Standard. Performance surpasses conducted EMI requirements of EN55022/FCC Class B by 10 dB, typ.
DC Output .....	See table. (Note 2.)
Continuous Output Power .....	40W, maximum.
Output Voltage Adjust .....	Primary output adjustable $\pm 5\%$ . Auxiliary outputs fixed.
Efficiency .....	62-75%, typical (nominal input line voltage, nominal load conditions).
Hold-Up Time .....	FLU models: 16 ms (115 VAC input), 32 ms (230 VAC input), minimum, at full load
Overload Protection .....	Power-limit circuit.
Short-Circuit Protection .....	Continuous.
Over-Voltage Protection .....	Primary output only.
Soft Start .....	Standard on all models.
Design Topology .....	Flyback converter with current-mode control.
Frequency of Operation .....	40 kHz (fixed).
Electrical Strength/Isolation .....	5300 VDC, input-to-output for one minute. (Note 6.)
Noise, Ripple and Spike .....	1% peak-to-peak, maximum. (See Note 8.)
Temperature Range .....	-20°C to +70°C.
Output Power De-Rating .....	De-rate output power and current linearly 2%/°C from +50°C to +70°C.
Temperature Coefficient .....	$\pm 0.05\%/^{\circ}\text{C}$ over the entire operating temperature range.
Relative Humidity .....	0 to 95%, non-condensing.
Altitude .....	0 to 10,000 feet.
Cooling .....	Convection cooling is adequate. Moving air is recommended for operation in a confined area.
Storage Temperature .....	-40°C to +85°C.
Storage Humidity .....	0 to 95%, non-condensing.
Mean Time Between Failures .....	>200,000 hours. (Note 9.)

Model	Output Voltage Output (V)	Output Current			Output Voltage Tol.	Line Reg.	Load Reg.	Cross-Reg.
		Min. (A)	Nom. (A)	Max. (A)				
<b>AC-DC Singles</b>					<b>85-265 VAC Input</b>			
FLU1-40-1AD	V1 5	0.0	8.00	8.00	1.0%	0.1%	0.2%	—
FLU1-40-2AD	V1 9	0.0	4.40	4.40	1.0%	0.1%	0.2%	—
FLU1-40-3AD	V1 12	0.0	3.30	3.30	1.0%	0.1%	0.2%	—
FLU1-40-4AD	V1 15	0.0	2.70	2.70	1.0%	0.1%	0.2%	—
FLU1-40-5AD	V1 24	0.0	1.70	1.70	1.0%	0.1%	0.2%	—
FLU1-40-6AD	V1 28	0.0	1.40	1.40	1.0%	0.1%	0.2%	—
<b>AC-DC Duals</b>					<b>85-265 VAC Input</b>			
FLU2-40-1AD	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +12	0.0	2.00	3.00	5.0%	0.5%	3.0%	4.0%
FLU2-40-3AD	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +24	0.0	1.00	1.50	5.0%	0.5%	3.0%	4.0%
FLU2-40-4AD	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +28	0.0	1.00	1.00	5.0%	0.5%	3.0%	4.0%
FLU2-40-7AD	V1 15(ISO)	0.0	1.50	2.50	1.0%	0.2%	1.0%	—
	V2 15(ISO)	0.0	1.20	2.00	3.0%	0.5%	1.0%	1.0%
<b>DC-DC Dual</b>					<b>36-75 VDC Input</b>			
DC2-40-1AC	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +12	0.0	2.00	3.00	5.0%	0.5%	3.0%	4.0%
<b>AC-DC Triples</b>					<b>85-265 VAC Input</b>			
FLU3-40-1AD	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +12	0.0	1.50	3.00 <sup>3</sup>	5.0%	1.0%	3.0%	4.0%
	V3 -12	0.0	0.50	0.70	5.0%	0.2%	1.0%	1.0%
FLU3-40-2AD	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +12	0.0	1.50	3.00 <sup>3</sup>	5.0%	1.0%	3.0%	4.0%
	V3 -5	0.0	1.00	1.00	3.0%	0.2%	1.0%	1.0%
FLU3-40-3AD	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +15	0.0	1.20	2.00 <sup>4</sup>	5.0%	1.0%	3.0%	4.0%
	V3 -15	0.0	0.50	0.60	5.0%	0.2%	1.0%	1.0%
FLU3-40-4AD	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +24	0.0	0.75	1.50 <sup>5</sup>	5.0%	1.0%	3.0%	4.0%
	V3 -12	0.0	0.50	0.70	5.0%	0.2%	1.0%	1.0%
FLU3-40-5AD	V1 5(ISO)	0.0	5.00	6.00	1.0%	0.2%	0.5%	—
	V2 12(ISO)	0.0	0.30	0.50	4.0%	0.5%	1.0%	1.0%
	V3 12(ISO)	0.0	0.30	0.50	4.0%	0.5%	1.0%	1.0%
FLU3-40-6AD	V1 5(ISO)	0.0	5.00	6.00	1.0%	0.2%	0.5%	—
	V2 15(ISO)	0.0	0.30	0.50	4.0%	0.5%	1.0%	1.0%
	V3 15(ISO)	0.0	0.30	0.50	4.0%	0.5%	1.0%	1.0%
<b>DC-DC Triple</b>					<b>36-75 VDC Input</b>			
DC3-40-1AC	V1 +5	0.0	3.00	5.00	1.0%	0.2%	1.0%	—
	V2 +12	0.0	1.50	3.00 <sup>3</sup>	5.0%	1.0%	3.0%	4.0%
	V3 -12	0.0	0.50	0.70	5.0%	0.2%	1.0%	1.0%



# 40W

## OPEN-FRAME SWITCHING POWER SUPPLIES



### FLU AND DC 40W SERIES

- A. Dimensions shown are in inches.  
 B. Tolerances = 0.00 ±0.01 inch.  
 0.000 ±0.005 inch.  
 C. P1 input connectors are Molex 26-62-4030. The mating connector combines Molex housing 43061-0003 and crimp terminal 08-70-1030.  
 D. P2 output connectors for the 40W series, except for models 5 and 6 of the FLU3-40 series, are Molex 26-60-4060. The mating connector combines Molex housing 43061-0006 and crimp terminal 08-70-1030. Models 5 and 6 of the FLU3-40 series use Molex 26-60-4080 for the P2 connector. The mating connector uses Molex housing 43061-0008 and crimp terminals 08-70-1030.

### Pin-Out

Pin	FLU1-40	FLU2-40 Models 1, 3	FLU2-40 Models 4, 7	DC2-40	FLU3-40 Models 1-4	FLU3-40 Models 5-6	DC3-40
1	V1	V2	+V1(ISO)	V2	V2	+V2(ISO)	V2
2	V1	V1	+V1(ISO)	V1	V1	- V2(ISO)	V1
3	V1	V1	- V1(ISO)	V1	V1	+V1(ISO)	V1
4	Return	Common	- V1(ISO)	Common	Common	+V1(ISO)	Common
5	Return	Common	- V2(ISO)	Common	Common	- V1(ISO)	Common
6	Return	N/C	+V2(ISO)	N/C	V3	- V1(ISO)	V3
7	N/A	N/A	N/A	N/A	N/A	+V3(ISO)	N/A
8	N/A	N/A	N/A	N/A	N/A	- V3(ISO)	N/A

### Notes

- Replace the input line fuse with the same type and rating. Recommended: 2A/250V slow-blow fuse.
- The sum of primary and auxiliary output currents from triple output models -1AD through -4AD must not exceed 5.0A.
- Peak output current rating = 5.0A (<60 seconds, duty cycle <10%).
- Peak output current rating = 3.0A (<60 seconds, duty cycle <10%).
- Peak output current rating = 2.0A (<60 seconds, duty cycle <10%).
- Electrical strength/isolation is 2200 VDC from the input of the power supply to ground for 60 seconds.
- All measurements are made directly at the terminals of the power supply.
- Peak-to-peak and RMS metering equipment must have a 20 MHz frequency response with probes and cables that maintain a frequency response of 20 Hz to 20 MHz. Output ripple and spikes are measured directly at the output terminals of the power supply with a 0.1 µF ceramic capacitor. The probe ground band must make direct contact with the output return or common terminal to prevent erroneous noise measurements.
- MTBF is calculated using the parts stress method in MIL-HDBK 217F (ground benign, TA = +25°C).
- Output voltage tolerance is measured under nominal load current conditions.
- Line regulation is measured under nominal load conditions as the input voltage is varied from 85 to 265 VAC (ac-input models) or from 36 to 75 VDC (dc-input models).
- Load regulation is measured at 115 VAC or 230 VAC. For single output models, load regulation is measured while output current is varied from 0% to 100% of full load. With multiple output models, the output under test is brought to 60% of nominal load; load current is then varied +40%/-30% of nominal while other outputs are held at nominal load conditions.
- Cross-regulation is tested by changing the load on the primary output from 50% to 100% of nominal load while measuring the voltage change on the auxiliary output under test.
- The FLU1-40, FLU2-40 and FLU3-40 series are approved to UL1950 (File E140439), CSA22.2 No. 234 (File LR52335), EN60950/IEC950/DIN VDE 0805 (TUV Licenses R9679206, R9779161, R9779037), and Austel CCL (Certificate A92/PS/004).
- The FLU3-40 series has BABT/EN41003 approval /4199/123/R/604674).
- The DC2-40 and DC3-40 series are approved to UL1950 (File E140439), CSA22.2 No. 234 (File LR52335), and EN60950/IEC950/DIN VDE 0805 (TUV License R9071501).